LIMITED ONE YEAR WARRANTY

This product is warranted to the retail consumer for **ONE**

YEAR from the date of retail purchase against defects in material and workmanship.

You should retain the original sales receipt / invoice as proof of date of purchase.

If no receipt is produced, this product is warranted for one year from date of manufacture.

What is covered

Replacement parts and labour

What is not covered

- 1. Transportation charges to and from authorised service centre for defective product.
- 2. Damage caused by modification, abuse, improper storage and maintenance.
- 3. Any other expense.

www.gareguns.com



PRE CHARGED PNEUMATIC AIRGUN OWNER'S MANUAL

Read all Instructions Carefully before using this Airgun

GANDIVA ADVANCED RESEARCH & EQUIPMENTS PVT. LTD.

No. 83, Sy. No. 36&39, Bidadi Industrial Area, 2nd Phase, Shyanumangala Village, Ramanagar Tg. & Dist - 562 109. Karnataka INDIA

www.gareguns.com



PARTS OF YOUR NEW AIR RIFLE



A. Recoil Pad

B. Cheek Rest

C. Side Lever

D. Pressure Gauge

E. Shroud

F. Barrel

G. Air Reservoir

H. Stock

I. Quick Fill Port

J. Safety

K. Trigger

L. Trigger Guard

Operating Instructions

Caution: Like all mechanical devices airgun may also fail.

Follow instruction for safe use

Filling the Air rifle using SCBA

- 1. Always wear eye protection
- 2. Make sure the Airgun is unloaded and Safety is ON
- 3.Fit the Quick connect coupler on the quick fill port under the belly of the Airgun
- 4. Close the bleed valve in the SCBA cylinder
- 5. Slowly start filling the rifle by opening the SCBA valve
- 6.Fill not more than 220 bar of pressure
- 7.Close the SCBA Valve
- 8. Open the bleed valve and Bleed the Air between SCBA and the Airgun
- 9. Disconnect the Qucik Fill probe

➤ Filling the Air rifle using Hand Pump

- 1. Always wear eye protection
- 2. Make sure the Airgun is unloaded and Safety is ON
- 3. Fit the Quick connect coupler on the quick fill port under the belly of the Airgun
- 4. Close the bleed valve in the Handpump
- 5. Slowly start filling the rifle by pumping
- 6. Fill not more than 220 bar of pressure
- 7.Open the bleed valve and Bleed the Air between PUMP and the Airgun
- 8.Disconnect the Fill probe

➤ Loading the Magazine

- 1.Start rotating the pellet Holder in the magazine in Anticlockwise direction
- 2. Keeping the spring tension in place
- 3.Insert .177 cal pellets one by one Head first inside the pellet holes in magazine
- 4.Load all the 10 pellets repeating the same process keeping the spring tension in place.

➤ Loading/Cocking and Firing the Rifle

- 1.Engage the safety
- 2. Point the gun in a safe Direction
- 3.Pull the Side Lever back gently to the coking position until the gun is cocked
- 4. Insert the Loaded Magazine or Place a pellet on the Single shot tray
- 5. Push the Side Lever forward Completely in place
- 6.Point the gun towards the intended target Release the safety and Gently squeeze the Trigger to fire the Gun.

➤ Important Point to Note:

- 1. Take necessary precautions before shooting
- 2. Always wear eye and ear protection
- 3. Do not fill the Airgun more than 200 bar of pressure
- 4. Never Point the Airgun at any living Beings
- 5. Always point the gun in a safe direction while loading and Unloading the Gun



GANDIVA ADVANCED RESEARCH & EQUIPMENTS PVT. LTD.

No. 83, Sy. No. 36&39, Bidadi Industrial Area, 2nd Phase, Shyanumangala Village, Ramanagar Tq. & Dist - 562 109. Karnataka INDIA



TECHNICAL SPECIFICATION

Calibre : 0.177 (4.5mm)

Barrel Length : 19.7 inch (Rifled)

Grooves : 12

Outer Diameter (Barrel) : 12 mm

Total Length : 1100 mm

Weight : 4 Kg

Stock : Beech Wood

Cylinder Capacity : 450cc

Working Pressure : 220 bar / 3200 psi

Number of Shots per Fill : 160

Velocity : 850 fps

Energy : 15 ft/lb or 20 Joules

Safety : Trigger Blocking Safety

Suppression : Fully Shrouded

Action : Side Lever Action

Magazine : 10 Shots

This package contains

1. BHIM PCP Air Rifle 2. Magazine 3. Sample Pellets 4. Instruction Manual



This airgun is recommended for adult use only. Misuse or careless use may cause serious injury or death. May be dangerous upto 500 meters.

Airguns with muzzle energy less than 20 J or 15 Ft. Lbs are exempt from licensing as per Arms Act. However, do not brandish or display this airgun in public - law enforcement personnel and others may think it is a fire arm.

Contains no user serviceable parts. Do not disassemble.

Use only compressed air in this airgun. Do not use any other gases.

REMEMBER TO ALWAYS TREAT THIS AIRGUN AS THOUGH IT IS LOADED AND WITH THE SAME RESPECT YOU WOULD TREAT A FIRE ARM

SAFE USAGE:

- i) ALWAYS treat the air rifle as though it is loaded and ready to fire.
- ii) ALWAYS store the air rifle unloaded and away from children.
- iii) ALWAYS aim the air rifle in safe direction.
- iv) ALWAYS keep the muzzle of the air rifle pointed in a safe direction.
- v) ALWAYS keep the finger off the trigger and out of the trigger guard until ready to shoot.
- vi) ALWAYS wear shooting glasses over reading or prescription glasses.
- vii) ALWAYS place shooting backstop in a location that is safe.
- viii) ALWAYS use correct size ammunition in your air rifle.
- ix) NEVER reuse ammunition.
- x) NEVER shoot at hard surfaces or water.
- xi) NEVER attempt to disassemble or tamper with air rifle. This will void the warranty of the air rifle and also render the air life dangerous to use.